



ZOLFO DISCHI

COMPOSITION

Sulfur, bentonite, calcium stearate.

GENERAL FEATURES

Appearance: round, yellowish tablet with average weight of 10 grams/each.

ZOLFO DISCHI is produced from pure sulfur using a special procedure that results in an even and regular combustion of sulfur, while avoiding dripping and hydrogen sulfide formation.

ZOLFO DISCHI does not crumble during use.

APPLICATIONS

ZOLFO DISCHI is indispensable for the sanitization and hygiene of wooden barrels and casks of any volume and dimension. It also functions in a complimentary manner with detergents (SANATON and DETERSOL) to ensure barrel hygiene prior to filling barrels or for when storing empty barrels.

Additionally ZOLFO DISCHI can be used as an oxygen scavenger, to reduce oxygen in tanks or other receptacles prior to filling.

DOSAGE

One tablet of ZOLFO DISCHI releases about 11.5 g of SO₂ and consumes oxygen contained in 20 liters of air.

Normal practice is to use one tablet to sanitize 250-500 L (66-132) barrels.

INSTRUCTIONS FOR USE

Place one or more ZOLFO DISCHI tablets on a wire or other device for hanging them inside barrels. Ignite the disc and place inside barrel and burn completely.

Do not breathe the fumes as they may be asphyxiating. When disc has burned out, remove it and close the barrel.

PACKAGING AND STORAGE

1 kg

Sealed package: store in a cool, dry, well-ventilated area.

Opened package: carefully reseal and store as indicated above.